


PUMP OPERATIONS & MAINTENANCE MANUAL







A300 - 3 INCH AIR OPERATED DOUBLE DIAPHRAGM PUMP

TABLE OF CONTENTS

SECTION 1	WARNINGS, DANGERS AND CAUTIONS	3
SECTION 2	MODEL DESIGNATION MATRIX	4-5
SECTION 3	PRINCIPLES OF OPERATION	6
SECTION 4	DIMENSIONAL DRAWINGS	7-8
SECTION 5	PERFORMANCE CURVES	
	RUBBER DIAPHRAGMS	9
	TPE DIAPHRAGMS	9
	PTFE DIAPHRAGMS	9
SECTION 6	INSTALLATION	
	INSTALLATION	10-11
	TROUBLESHOOTING	12
	OPERATION	13
	MAINTENANCE	13
SECTION 7	REPAIR AND ASSEMBLY	
	PUMP WET END REMOVAL	14-15
	AIR VALVE REMOVAL	16-17
	PILOT VALVE REMOVAL	18-19
	TORQUE SPECIFICATION CHART	19
SECTION 8	EXPLODED VIEWS & PARTS LIST	
	THREADED ALUMINUM	20-22
	FLANGED STAINLESS STEEL	23-25
SECTION 9	ELASTOMERS AND REPAIR KITS	26
SECTION 10	WARRANTY AND REGISTRATION	27





CAUTIONS — READ FIRST!

READ THESE WARNINGS AND SAFETY PRECAUTIONS PRIOR TO INSTALLATION OR OPERATION, FAILURE TO COMPLY WITH THESE INSTRUCTIONS COULD RESULT IN PERSONAL INJURY AND OR PROPERTY DAMAGE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

MARNING Pump, valves and all containers must be properly grounded prior to handling flammable fluids and/or whenever static electricity is a hazard.

WARNING Prior to servicing the pump, ensure that the air and fluid lines are closed and disconnected. While wearing personal protective equipment, flush, drain and process liquid from the pump in a safe manner.

WARNING The TX marking refers to the maximum surface temperature depending not on the equipment itself, but mainly on operating conditions. In this case, the maximum surface temperature depends upon the temperature of the process fluids.

CAUTION The temperature of the process fluid and air input must be no more than 36°F (20C) less of the maximum temperature allowed for the appropriate nonmetallic material. See the list of temperatures below for each material's maximum recommended temperature:

Buna-N (Nitrile): 10°F to 180°F (-12C to 8		
Geolast®:	10°F to 180°F (-12C to 82C)	
EPDM:	-40°F to 280°F (-40C to 138C)	
Santoprene®:	-40°F to 225°F (-40C to 107C)	
Viton® (FKM):	-40°F to 350°F (-40C to 177C)	
PTFE:	40°F to 220°F (4C to 104C)	
Polyethylene: 32°F to 158°F (0C to 700		
Polypropylene: 32°F to 180°F (0C to 820		
PVDF: 0°F to 250°F (-18C to 121		
Nylon:	0°F to 200°F (-18C to 93C)	

Temperature limits are solely based upon mechanical stress and certain chemicals will reduce the maximum operating temperature. The allowable temperature range for the process fluid is determined by the materials in contact with the fluid being pumped. Consult a chemical resistance guide for chemical compatibility and a more precise safe temperature limit. Always use minimum air pressure when pumping at elevated temperatures.

CAUTION Do not lubricate air supply.

! WARNING = Hazards or unsafe practices which could result in severe personal injury, death or substantial property damage

A CAUTION

= Hazards or unsafe practices which could result in minor personal injury, product or property damage.

CAUTION Do not connect a compressed air source to the exhaust port of the pump.

A WARNING Use only with liquid process fluid.

MARNING Maintenance must not be performed when a hazardous atmosphere is present.

CAUTION Do not exceed 120 psig (8.3 bar) air-inlet pressure.

A CAUTION Do not exceed 10 psig (0.7 bar) or 23 ft-H₂O suction pressure.

CAUTION Ensure all wetted components are chemically compatible with the process fluid and the cleaning fluid.

CAUTION Ensure pump is thoroughly cleaned and flushed prior to installation into a process line.

CAUTION Always wear Personal Protective Equipment (PPE) when operating pump.

CAUTION Close and disconnect all compressed air and bleed all air from the pump prior to service. Remove all process fluid in a safe manner prior to service.

CAUTION Blow out all compressed air lines in order to remove any debris, prior to pump installation. Ensure that the muffler is properly installed prior to pump operation.


CAUTION Ensure air exhaust is piped to atmosphere prior to a submerged installation.

CAUTION Ensure all hardware is set to correct torque values prior to operation.







MODEL DESIGNATION MATRIX - ALUMINUM



4 seat O-rings (if required). See matrix below.











MODEL DESIGNATION MATRIX - STAINLESS STEEL




WET END REPAIR KIT

Wet end kits are available and consist of 2 diaphragms, (back-up diaphragms if required), 4 balls, 4 seats, and 4 seat O-rings (if required). See matrix below.



AIR END REPAIR KIT


Air end repair kit contains pilot sleeve assembly and main air valve.





PRINCIPLES OF OPERATION


HOW AN AIR OPERATED DOUBLE DIAPHRAGM PUMP WORKS



The air-valve directs pressurized air behind the diaphragm on the right, causing the diaphragm on the right to move outward (to the right).

Since both the right diaphragm and the left diaphragm are connected via a diaphragm rod, when the right diaphragm moves to the right, the left diaphragm (through the action of the diaphragm rod) moves to the right also.

When the diaphragm on the left side is moving to the right, it is referred to as suction stroke. When the left diaphragm is in its suction stroke, the left suction ball moves upward (opens) and the left discharge ball moves downward (closes). This action creates suction and draws liquid into the left side chamber.



The air-valve directs pressurized air behind the left diaphragm, causing the left diaphragm to move outward (to the left).

Since both the left diaphragm and the right diaphragm are connected via a diaphragm rod, when the left diaphragm moves to the left, the right diaphragm (through the action of the diaphragm rod) moves to the left also.

When the diaphragm on the left side moves outward, the left discharge ball moves upward (opens) and the left suction ball moves downward (closes). This causes the liquid to leave the left side liquid outlet of the pump.


Simultaneously, the right diaphragm moves inward (to the left), which causes the right suction ball to open and the right discharge to close, which in turn causes suction, drawing liquid into the right chamber.


The process of alternating right suction / left discharge (and vice-versa) continues as long as compressed air is supplied to the pump.



PUMP DIMENSIONS

ALUMINUM - THREADED







st Note - Suction Center Front / Discharge Center Rear are default ports. See part number matrix option code for additional porting options.



PUMP DIMENSIONS

STAINLESS STEEL - FLANGED







^{*} Note - Suction Center Front / Discharge Center Rear are default ports. See part number matrix option code for additional porting options.




PERFORMANCE CURVES



Performance Specification	IS
Max. Flow:	235 gpm (890 lpm)
Max. Air Pressure:	120 psi (8.3 bar)
Max. Solids:	7/16" (11 mm)
Max. Suction Lift Dry:	20 ft-H ₂ 0 (6.1 m-H ₂ 0)
Max. Suction Lift Wet:	31 ft-H ₂ 0 (9.4 m-H ₂ 0)
Weight: AL-135 lbs (62	2 kg) / SS-300 lbs (136 kg)
Air Inlet:	3/4" FNPT
Liquid Inlet: 3" FNPT, 3" FE	SSPT, or ANSI/DIN Flanged
Liquid Outlet: 3" FNPT, 3" FE	SSPT, or ANSI/DIN Flanged
Height: 32.6" (827 m	m) AL / 35.2" (893mm) SS
Width:	24.8" (630 mm)
Depth:	16.8" (425 mm)



Performance Specifica	tions
Max. Flow:	235 gpm (890 lpm)
Max. Air Pressure:	120 psi (8.3 bar)
Max. Solids:	7/16" (11 mm)
Max. Suction Lift Dry:	20 ft-H ₂ 0 (6.1 m-H ₂ 0)
Max. Suction Lift Wet:	31 ft-H ₂ 0 (9.4 m-H ₂ 0)
Weight: AL-135 lbs	s (62 kg) / SS-300 lbs (136 kg)
Air Inlet:	3/4" FNPT
Liquid Inlet: 3" FNPT, 3	" FBSPT, or ANSI/DIN Flanged
Liquid Outlet: 3" FNPT, 3	" FBSPT, or ANSI/DIN Flanged
Height: 32.6" (82	7 mm) AL / 35.2" (893mm) SS
Width:	24.8" (630 mm)
Depth:	16.8" (425 mm)



Performance	e Specificat	ions
Max. Flow:		235 gpm (890 lpm)
Max. Air Pres	sure:	120 psi (8.3 bar)
Max. Solids:		7/16" (11 mm)
Max. Suction	Lift Dry:	17 ft-H ₂ 0 (5.2 m-H ₂ 0)
Max. Suction	Lift Wet:	31 ft-H ₂ 0 (9.4 m-H ₂ 0)
Weight:	AL-135 lbs	(62 kg) / SS-300 lbs (136 kg)
Air Inlet:		3/4" FNPT
Liquid Inlet:	3" FNPT, 3"	FBSPT, or ANSI/DIN Flanged
Liquid Outlet:	3" FNPT, 3"	FBSPT, or ANSI/DIN Flanged
Height:	32.6" (827	mm) AL / 35.2" (893mm) SS
Width:		24.8" (630 mm)
Depth:		16.8" (425 mm)

^{*}Flow rates indicated on all three charts shown were determined by pumping water at flooded suction.

For optimum life and performance, pumps should be specified so that daily operation parameters will fall in the center of the pump performance curve.





INSTALLATION, TROUBLE-SHOOTING AND MAINTENANCE

INSTALLATION PIPING

Whenever possible ensure the pump is installed using the shortest possible pipe lengths with the minimum amount of pipe fittings. Ensure all piping is supported independent of the pump.

Suction and discharge piping should not be smaller than the connection size of the pump. When pumping liquids of high viscosity, larger piping may be used, in order to reduce frictional pipe loss.

Employ flexible hoses in order to eliminate the vibration caused by the pump. Mounting feet can also be used to reduce vibration effects.

All hoses should be reinforced, non-collapsible and be capable of high vacuum service. Ensure that all piping and hoses are chemically compatible with the process and cleaning fluid.

For processes where pulsation effects should be reduced, employ a pulsation dampener on the discharge side of the pump.

For self-priming applications, ensure all connections are airtight and the application is within the pumps dry-lift capability. Refer to product specifications for further details.

For flooded suction applications, install a gate valve on the suction piping in order to facilitate service.

For unattended flooded suction operation, it is recommended to pipe the exhaust air above the liquid source. In the event of a diaphragm failure this will reduce or eliminate the possibility of liquid discharging through the exhaust onto the ground.

LOCATION

Ensure that the pump is installed in an accessible location, in order to facilitate future service and maintenance.

AIR

Ensure that the air supply is sufficient for the volume of air required by the pump. Refer to product specifications for further details. For reliable operation, install a 5 micron air filter, air-valve and pressure regulator. Do not exceed the pumps maximum operating pressure of 120 psig.

REMOTE OPERATION

Utilize a three way solenoid valve for remote operation. This ensures that air between the solenoid and the pump is allowed to "bleed off," ensuring reliable operation. Liquid transfer volume is estimated by multiplying displacement per stroke times the number of strokes per minute

NOISE

Correct installation of the muffler reduces sound levels. Refer to product specifications for further details.

SUBMERGED OPERATION

For submersible operation, pipe the air exhaust to atmosphere


GROUNDING THE PUMP

Loosen grounding screw and install a grounding wire. Tighten grounding screw. Wire size should be a 12 gauge wire or larger. Connect the other end of the wire to a true earth ground. Equipment must be grounded to achieve ATEX rating and it is recommended to configure the pump with a grounding lug option.





SUGGESTED INSTALLATION



This illustration is a generic representation of an air operated double-diaphragm pump.



TROUBLESHOOTING

PROBLEM

EFFECT/SOLUTION

Pump Will Not Cycle

Discharge line closed or plugged

Discharge filter blocked Check valve stuck Air filter blocked

Air supply valve closed

Air supply hooked up to muffler side of pump Compressor not producing air or turned off

Muffler iced or blinded Diaphragm ruptured

Plant air supply line ruptured

Air valve wear/debris Pilot sleeve wear/debris Diaphragm rod broken Diaphragm plate loose

Pumped Fluid Coming Out of Muffler

Diaphragm ruptured Diaphragm plate loose

Inlet liquid pressure excessive (above 10 psig)

Pump Cycles but no Flow

Inlet strainer clogged
Suction valve closed
Suction line plugged
No liquid in the suction tank
Suction lift excessive
Debris stuck in valves

Excessive wear of check valves

Air leak on suction side with suction lift

Pump Cycles with Closed Discharge Valve

Debris stuck in check valve Excessive wear of check valves

Pump Running Slowly/Not Steady

Air compressor undersized

Leak in air supply

Air-line, filter regulator or needle valve undersized

Muffler partially iced or blinded Air valve gasket leak or misalignment

Air valve wear/debris Pilot sleeve wear/debris Liquid fluid filter blocked

Pump may be cavitating, reduce speed of operation

Suction strainer clogged

Pump Will Not Prime

Air leak in suction pipe

Air leak in pump manifold connections Suction strainer and lines clogged

Excessive lift conditions Check valve wear Debris in check valve





OPERATION

The Air-Operated Double Diaphragm Pump requires a minimum of 20 psig of air to operate, with some variation according to diaphragm material. Increasing the air pressure results in a more rapid cycling of the pump and thus a higher liquid flow rate. In order to not exceed 120 psig of inlet air pressure, and for accurate control of the pump, it is suggested to use a pressure regulator on the air inlet.

An alternate means of controlling the flow-rate of the pump is to use an inlet air valve and partially open or close accordingly. When the air valve is completely in the closed position, the pump will cease to operate.

A third method of controlling the flow rate of the pump is to use a liquid discharge valve. Closing the liquid discharge valve will cause a decrease in the flow rate since the pump will operate against a higher discharge pressure.

Solenoid control of the inlet air may also be used in order to facilitate remote operation. A three way solenoid valve is recommended, in order to allow the air to "bleed off" between the solenoid and the pump.

Do not use valves for flow control on the suction side of the pump. (Closing or partially closing a liquid suction valve restrict the suction line and may cause damage to the diaphragms.) Suction strainers may be employed to reduce or eliminate larger solids, but routine maintenance is necessary in order to prevent a restriction on the suction.

MAINTENANCE

Due to the unique nature of each application, periodic inspection of the pump is the best method to determine a proper maintenance schedule. A record should be kept of all repairs made to an installed pump. This will serve as the best predictor of future maintenance.

Typical maintenance involves replacing of "wear-parts" such as the diaphragms, balls, valve seats and O-rings. Proper maintenance can ensure trouble-free operation of the pump. Refer to repair and assembly instructions for further details.

WARNING Maintenance must not be performed when a hazardous atmosphere is present.

MAINTENANCE SCHEDULE

WEEKLY (OR DAILY)

Make a visual check of the pump. If pumped fluid is leaking out of the pump, pipe fittings or muffler turn off pump and schedule maintenance.

EVERY THREE MONTHS

Inspect fasteners and tighten any loose fasteners to recommended torque settings.

Schedule pump service based on pump's service history.



REPAIR AND ASSEMBLY

PUMP WET END REMOVAL

TOOLS NEEDED

- 1) Two Wrenches, 3/4 Inch
- 2) Two Adjustable Wrenches or Vice
- 3) One Socket Wrench, 9/16 Inch
- 4) One Socket Wrench, 1-1/16 Inch
- 5) One Spanner Wrench, 3/4 Inch (May Be Required) - A vice may be required

WARNING Prior to servicing the pump, ensure that the air and fluid lines are closed and disconnected. While wearing personal protective equipment, flush, drain and process liquid from the pump in a safe manner.

WARNING Maintenance must not be performed when a hazardous atmosphere is present.



STEP 1

Using the 3/4 inch wrench remove six "Hex-Head Cap Screws (1/2"-13x2-1/2")", six "Flat & Lock Washers (1/2")" and six "Flanged Hex Nuts (1/2"-13)" from the "Discharge Manifold".



STEP 4

Using the 3/4 inch wrench remove six "Hex-Head Cap Screws (1/2"-13x2-1/2")", six "Flat & Lock Washers (1/2")" and six "Flanged Hex Nuts (1/2"-13)" from the "Suction Manifold".



STEP 2

Remove the "Discharge Manifold".



STEP 3

Remove the "O-Ring", "Valve Seat" and "Ball".

Note: some models have an integral rubber seat and seal.



STEP 5

Remove the "Suction Manifold".



STEP 6

Remove the "O-Ring", "Valve Seat" and "Ball".

Note: some models have an integral rubber seat and seal.





STEP 7

In order to remove both "Outer Chambers" use two ¾ Inch wrenches. Remove eight "Hex-Head Cap Screws (1/2"-13)", eight "Flat Washers (1/2")" and six "Flanged Hex Nuts (1/2"-13)" from each "Outer Chamber".



STEP 8

Remove both "Outer Chambers" from the "Intermediate."



STEP 9

Using two adjustable wrenches (or a wrench 1-5/32" and a vice), remove "Outer Diaphragm Plate", "Diaphragm" & "Inner Diaphragm Plate" from one side of the pump.



STEP 10

Remove the "Bumper" and large "Washer" (2-3/8") from the threaded rod stud (Aluminum models only).



STEP 11

Using the 9/16 inch socket wrench, remove six "Hex-Head Cap Screws (3/8"-16x1-1/4") and six "Washers" (3/8"). Remove "Inner Diaphragm Plate" and "Outer Diaphragm Plate" from "Diaphragm."

PUMP WET END ASSEMBLY

To assemble the wet end of the pump, reverse the order of disassembly. Ensure all hardware is fastened in accordance with torque specifications (see page 19). Inverting one of the diaphragms during reassembly will facilitate ease of assembly.

Note: Shorter bolts (1-1/2") are used at 6 and 12 O'Clock position of the chamber bolt patterns and thread directly into blind tapped holes (no nuts).



REPAIR AND ASSEMBLY

AIR VALVE REMOVAL

TOOLS NEEDED

- 1) One Wrench, 7/16 Inch
- 2) One Pick, General Purpose
- 3) One Pair of Pliers

WARNING Prior to servicing the pump, ensure that the air and fluid lines are closed and disconnected. While wearing personal protective equipment, flush, drain and process liquid from the pump in a safe manner.

WARNING Maintenance must not be performed when a hazardous atmosphere is present.



STEP 1

Using the $^{7}/_{16}$ inch wrench, remove eight "Hex Head Cap Screws $(1/4"-20 \times 3")"$, eight "Lock Washers (1/4)" and eight "Flat Washers (1/4)".



STEP 2

Remove the main "Air-Valve Assembly" from the pump.



STEP 3


Remove the "Air-Valve Gasket" from the main "Air-Valve Assembly".



STEP 4


Remove the "Shuttle Plate" from the main "Air-Valve Assembly".

Note: The smooth shinny side of the shuttle plate should be toward the shuttle car.



STEP 5


Remove the "Shuttle" from the main "Air-Valve Assembly".



STEP 6

Using the pair of pliers, remove the "Air Valve End Plug" from the main "Air-Valve Assembly".

Ensure the "O-Ring" is installed when reassembling.



STEP 7

Remove the "Air Valve Spool" from the main "Air-Valve Assembly".



STEP 10A


Air Valve Orientation

The longer piston with the leading chamfer is to be on the top facing up. Arrow points up on the main air valve casting.



STEP 8

Using the pick, remove the "Lip Seal (Air Valve)" from the main "Air-Valve Assembly".



STEP 10B

Spool Orientation



STEP 9

Using the pick, remove the second "Lip Seal (Air Valve)" from the main "Air-Valve Assembly".

AIR VALVE ASSEMBLY

To assemble the air valve, reverse the order of disassembly. During assembly, ensure that the open side of the lip-seals are both facing each other inward. Install the shuttle plate with the smooth/shinny side toward the shuttle car. Lubrication of the air valve assembly, with a non-synthetic lubricant, is recommended. Magna-Lube or Magna-Plate are recommended for assembly lubrication (see detailed parts list for ordering information).

Note that if the lip-seals are installed incorrectly, they will be unable to rotate. Insert the spool, the spool's longer piston with leading chamfer is to be on the top side of the air valve casting, ensure O-Rings are installed, and then the air-valve end plugs into position.

REPAIR AND ASSEMBLY

PILOT VALVE REMOVAL

TOOLS NEEDED

1) One Screwdriver, Phillips #2
2) Two Wrenches, 3/4 Inch
The chambers do not need to be removed for this procedure.
The graphics show the inner chambers removed for clarity.

WARNING Prior to servicing the pump, ensure that the air and fluid lines are closed and disconnected. While wearing personal protective equipment, flush, drain and process liquid from the pump in a safe manner.

WARNING Maintenance must not be performed when a hazardous atmosphere is present.



STEP 1

Using the screwdriver, remove three "Phillips Flat Head Mach Screw (#6-32-x 3/4")" in order to remove the "Retaining Plate".
Repeat for both sides of the pump.



STEP 2

Remove the "Diaphragm Rod" and the "Pilot Sleeve Assembly" from the "Intermediate".



STEP 3

Remove the "Lip Seal" and "End Spacer".



STEP 4

Remove "O-rings" and "Inner Spacer".



STEP 5

Remove "Pilot Sleeve" from diaphragm rod. The two piece rod must be disassembled to remove the "Pilot Sleeve". Use the 3/4 inch wrenches to separate the rod. Note they are installed with threadlocker.

PILOT VALVE ASSEMBLY

To assemble the pilot valve, reverse the order of disassembly. Should process fluid have contact with the pilot valve o-rings, they should be replaced as swelling may occur and cause irregular operation. During assembly, ensure that the open side of the lip-seals are facing outward. Lubrication of the pilot sleeve assembly, with a non-synthetic lubricant, is recommended in order to facilitate re-assembly into the intermediate. Magna-Lube or Magna-Plate are recommended for assembly lubrication (see detailed parts list for ordering information).

TORQUE SPECIFICATION CHART


RECOMMENDED TORQUE SPECIFICATIONS

	3" Pumps	Wrench Size	
Manifold Bolts	50 ft-lbs (67.8 N-m)	3/4"	
Chamber Bolts	30 ft-lbs (40.7 N-m)	3/4"	
Air Valve Bolts	40 in-lbs (4.5 N-m)	7/16"	
Inner/Outer Diaphragm Plate Bolts	12.5 ft-lbs (16.9 N-m)	9/16"	
Chamber/Intermediate Bolts	10 ft-lbs (13.6 N-m)	1/4" (Hex)	
Diaphragm Rod	Tighten until mechanical interference (hard stop then 1/8 to 1/4 turn more		



EXPLODED VIEW & PARTS LIST

ALUMINUM, A300-*AA-***-***



PARTS LIST - ALUMINUM, A300-*AA-***-***

A300-*A*-"	NO.	DESCRIPTION (YTÇ	PUMP MODEL	PART NO.	MATERIAL
BALL	10	DISCHARGE MANIFOLD	1	A300-NAA-***-**	10519-20-NPT	Aluminum
A300-A4-*F*-********************************				A300-BAA-***-***	10519-20-BSPT	Aluminum
A300-A4-*9-*********************************	20	BALL	4			•
A300-A*-*S**-*** 11007-21-APK Suntoprene* A300-A*-*S**-*** 11007-23-APK Suntoprene* Suntoprene* A300-A*-*T**-*** 11007-23-APK Suntoprene* A300-A*-*T**-*** 11007-23-APK Suntoprene* A300-A*-**** 11007-23-APK Suntoprene* A300-A*-**** 11007-51-APK Suntoprene* A300-A*-**** 10905-13-APK Suntoprene* A300-A*-**** 10905-13-APK Sund-A* A300-A*-**** 10905-13-APK Sund-A* A300-A*-***** 10905-13-APK Sund-A* A300-A*-***** 10905-13-APK Sund-A* A300-A*-***** 10905-20-APK Staintess Steel A300-A*-***** 10905-20-APK Staintess Steel A300-A*-****** 10905-20-APK Staintess Steel A300-A*-****** 10905-42-APK Staintess Steel A300-A*-***** 10905-42-APK Staintess Steel A300-A*-***** 10905-42-APK Staintess Steel A300-A*-***** 10905-42-APK Staintess Steel A300-A*-***** 11934-13-APK PTEE PDM A300-A*-****** 11934-13-APK PTEE PDM A300-A*-****** 11934-13-APK PTEE PDM A300-A*-****** 11934-13-APK PTEE A300-A*-******* 11934-13-APK PTEE A300-A*-******** 11934-13-APK PTEE A300-A*-********* 11934-13-APK PTEE A300-A*-********************************						
A300-A*-*S*-** 11007-23-APK Santoprene* A300-A*-***** 11007-23-APK PTFE						
A300-A*-*T*-**** 11007-45-APK PTE						
A300-*A*-*** EE-*** 10905-15-APK EPDM A300-*A*-*** NN-**** 10905-19-4PK Buna-N A300-*A*-*** NN-**** 10905-20-4PK Auminum A300-*A*-******** 10905-20-4PK Auminum A300-*A*-*********** 10905-26-4PK Stainless Steel A300-*A*-******** 10905-26-4PK Nylon Nylon A300-*A*-*********** 10905-26-4PK Nylon Nylon A300-*A*-*************** 10905-26-4PK Nylon Nylon A300-*A*-*******************************						
A300-*A***NN-*** 10905-19-4PK Buna-N A300-*A-***A***** 10905-20-4PK Adminium A300-*A-******* 10905-20-4PK Adminium A300-*A-******** 10905-22-4PK Stainless Steel A300-*A-******** 10905-22-4PK Stainless Steel A300-*A-******** 10905-22-4PK Stainless Steel A300-*A-********************************	30	VALVE SEAT	4		10905-13-4PK	Viton®/FKM
RA300-*A*-*******************************						
VALVE SEATS 10905-13, -15 & -19 HAVE A300-*A*-*******************************						
NTEGRAL VALVE & 0-RING A300-*A*-**Y*-*** 10905-42-4PK Nylon		(VALVE CEATS 10005 12 15 8 10 HAVE				
O-RING [VALVE SEAT]		· ·				
OPTIONAL- ONLY USED WITH A300-*A*-*****	40	O-RING (VALVE SEAT)	4			
A300-*A*-**3*-*** & A300-*A*-***** 11934-17-4PK PTFE						•
OUTER CHAMBER 2 A300-*AA-***** 10704-20						
61 INTERMEDIATE 1 All Models 11520-A300-20 Aluminum 62 INNER CHAMBER 2 All Models 11802-20 Aluminum 70 & 90 DIAPHRAGM ROD ASSEMBLY 1 A300-*AA-****-*** 35006-00 Stainless Steel 80 PILOT SLEEVE 1 All Models 10106-31 Δ Acetal 100 INNER SPACER, PILOT SLEEVE 3 All Models 10205-40 Δ Polypropylene 110 O-RING (PILOT SLEEVE SPACER) 4 All Models 11919-16 Δ Urethane 120 END SPACER, PILOT SLEEVE 2 All Models 10206-40 Δ Polypropylene 130 O-RING (END SPACER) 2 All Models 11919-11 Δ Nitrile 140 LIP SEAL (AIR VALVE) 2 All Models 12002-76 Δ Nitrile 150 RETAINING PLATE 2 All Models 12712-A300-20 Aluminum 160 BUMPER 2 All Models 11107-20 Aluminum 180 DIAPHRAGM 2						
1802-20 Aluminum 1802-2						
70 & 90 DIAPHRAGM ROD ASSEMBLY 1 A300-*AA-***** 35006-00 Stainless Steel						
80						
100 INNER SPACER, PILOT SLEEVE 3 All Models 10205-40 Δ Polypropylene 110 O-RING (PILOT SLEEVE SPACER) 4 All Models 11919-16 Δ Urethane 120 END SPACER, PILOT SLEEVE 2 All Models 10206-40 Δ Polypropylene 130 O-RING (END SPACER) 2 All Models 11919-11 Δ Nitrile 140 LIP SEAL (AIR VALVE) 2 All Models 12002-76 Δ Nitrile 150 RETAINING PLATE 2 All Models 12712-A300-20 Aluminum 160 BUMPER 2 All Models 12309-16 Urethane 170 INNER DIAPHRAGM PLATE 2 All Models 11107-20 Aluminum 180 DIAPHRAGM 2 A300-*A*-N***-*** 10608-11-2PK Buna-N 180 DIAPHRAGM 2 A300-*A*-E***-*** 10608-13-2PK Viton*/FKM 4 A300-*A*-F***-*** 10608-19-2PK Geolast* 4 A300-*A*-F***-*** 10608-23-2PK Santoprene*						
110 O-RING (PILOT SLEEVE SPACER) 4 All Models 11919-16 Δ Urethane 120 END SPACER, PILOT SLEEVE 2 All Models 10206-40 Δ Polypropylene 130 O-RING (END SPACER) 2 All Models 11919-11 Δ Nitrile 140 LIP SEAL (AIR VALVE) 2 All Models 12002-76 Δ Nitrile 150 RETAINING PLATE 2 All Models 12712-A300-20 Aluminum 160 BUMPER 2 All Models 12309-16 Urethane 170 INNER DIAPHRAGM PLATE 2 All Models 11107-20 Aluminum 180 DIAPHRAGM 2 A300-*A*-N**-*** 10608-11-2PK Buna-N A300-*A*-E******* 10608-13-2PK Viton*/FKM A300-*A*-G***-*** 10608-19-2PK Geolast* A300-*A*-G***-**** 10608-23-2PK Santoprene* (BACKUP) A300-*A*-T***-*** 11407-59-2PK PTFE 200 & 210 OUTER DIAPHRAGM PLATE W/THREADED STUD 2 A300-*AA-****-*** 11222-20 Aluminum 220 SUCTION MANIFOLD 1 A300-NAA-****-*** 10517-20-NPT Aluminum 230 GASKET, AIR VALVE 1 All Models 12115-19 ‡ Nitrile 240 SHUTTLE PLATE 1 All Models 10413-32 ‡ Special 260 AIR VALVE BODY 1 All Models 11613-20 ‡ Aluminum						
120 END SPACER, PILOT SLEEVE 2 All Models 10206-40 Δ Polypropylene 130 O-RING (END SPACER) 2 All Models 11919-11 Δ Nitrile 140 LIP SEAL (AIR VALVE) 2 All Models 12002-76 Δ Nitrile 150 RETAINING PLATE 2 All Models 12712-A300-20 Aluminum 160 BUMPER 2 All Models 12309-16 Urethane 170 INNER DIAPHRAGM PLATE 2 All Models 1107-20 Aluminum 180 DIAPHRAGM 2 A300-*A*-N***-*** 10608-11-2PK Buna-N A300-*A*-U***-*** 10608-11-2PK Buna-N A300-*A*-U***-*** 10608-13-2PK Viton®/FKM A300-*A*-E***-**** 10608-13-2PK Viton®/FKM A300-*A*-E***-*** 10608-13-2PK Santoprene® (BACKUP) A300-*A*-S***-*** 10608-13-2PK Santoprene® 190 OVERLAY (PTFE ONLY) 2 A300-*A*-T***-***** (PTFE) 10608-23-2PK Santoprene® 200 & 210 OUTER DIAPHRAGM PLATE W/THREADED STUD 2 A300-*A*-****-***** 11222-20 Aluminum <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
130						
140 LIP SEAL (AIR VALVE) 2 All Models 12002-76 Δ Nitrile 150 RETAINING PLATE 2 All Models 12712-A300-20 Aluminum 160 BUMPER 2 All Models 12309-16 Urethane 170 INNER DIAPHRAGM PLATE 2 All Models 11107-20 Aluminum 180 DIAPHRAGM 2 A300-*A*-N***-*** 10608-11-2PK Buna-N A300-*A*-E****-*** 10608-13-2PK Viton*/FKM A300-*A*-G***-*** 10608-13-2PK Viton*/FKM A300-*A*-G***-**** 10608-19-2PK Geolast* A300-*A*-G***-*** 10608-19-2PK Viton*/FKM A300-*A*-G***-*** 10608-23-2PK Santoprene* 190 OVERLAY (PTFE ONLY) 2 A300-*A*-T***-**** 11407-59-2PK PTFE 200 & 210 OUTER DIAPHRAGM PLATE W/THREADED STUD 2 A300-*AA-****-*** 11222-20 Aluminum 220 SUCTION MANIFOLD 1 A300-NAA-****-*** 10517-20-NPT Aluminum 230						
150 RETAINING PLATE 2 All Models 12712-A300-20 Aluminum 160 BUMPER 2 All Models 12309-16 Urethane 170 INNER DIAPHRAGM PLATE 2 All Models 11107-20 Aluminum 180 DIAPHRAGM 2 A300-*A*-N***-*** 10608-11-2PK Buna-N						
160 BUMPER 2 All Models 12309-16 Urethane 170 INNER DIAPHRAGM PLATE 2 All Models 11107-20 Aluminum 180 DIAPHRAGM 2 A300-*A*-N***-*** 10608-11-2PK Buna-N A300-*A*-V**-*** 10608-13-2PK Viton*/FKM A300-*A*-E**-*** 10608-13-2PK Urethane A300-*A*-E**-*** 10608-19-2PK Geolast* A300-*A*-S**-*** 10608-23-2PK Santoprene* A300-*A*-S**-*** 10608-23-2PK Santoprene* Santoprene* 190 OVERLAY (PTFE ONLY) 2 A300-*A*-T***-*** 11407-59-2PK PTFE 1008-210 OUTER DIAPHRAGM PLATE W/THREADED STUD 2 A300-*AA-***-*** 11222-20 Aluminum 1220 SUCTION MANIFOLD 1 A300-NAA-***-*** 10517-20-NPT Aluminum A300-BAA-***-*** 10517-20-BSPT A100-BAA-***-*** 10517-20-BSPT A100-BAA-***-*** 10517-20-BSPT A100-BAA-***-*** 10517-20-BSPT A100-BAA-***-*** 10517-20-BSPT A100-BAA-***-**** 10517-20-BSPT A100-BAA-***-***** 10517-20-BSPT A100-BAA-***-**** 10517-20-BSPT A100-BAA-***-***** 10517-20-BSPT			2			
170 INNER DIAPHRAGM PLATE 2 All Models 11107-20 Aluminum						
DIAPHRAGM		BUMPER				Urethane
A300-*A*-V***-*** 10608-13-2PK Viton®/FKM A300-*A*-E***-*** 10608-16-2PK Urethane A300-*A*-G**-*** 10608-16-2PK Urethane A300-*A*-G**-*** 10608-19-2PK Geolast® A300-*A*-S**-*** 10608-23-2PK Santoprene® A300-*A*-T**-*** 10608-23-2PK Santoprene® A300-*A*-T**-*** 11407-59-2PK PTFE 200 & 210 OUTER DIAPHRAGM PLATE W/ THREADED STUD 2 A300-*AA-****-*** 11222-20 Aluminum A300-*BAA-****-*** 10517-20-NPT Aluminum A300-*BAA-****-*** 10517-20-BSPT Aluminum A300-*BAA-****-*** 10517-20-BSPT Aluminum A300-*BAA-****-*** 10413-32 † Stainless Steel SHUTTLE PLATE 1 All Models 10413-32 † Special 260 AIR VALVE BODY 1 All Models 11613-20 † Aluminum Aluminum	170	INNER DIAPHRAGM PLATE	2		11107-20	Aluminum
A300-*A*-E***-*** 10608-16-2PK Urethane A300-*A*-G**-*** 10608-19-2PK Geolast® Geolast® A300-*A*-S**-*** 10608-23-2PK Santoprene® A300-*A*-T***-***(PTFE) 10608-23-2PK Santoprene® Santoprene® A300-*A*-T***-*** 11407-59-2PK PTFE 200 & 210 OUTER DIAPHRAGM PLATE W/THREADED STUD 2 A300-*A*-T***-*** 11222-20 Aluminum 220 SUCTION MANIFOLD 1 A300-NAA-****-*** 10517-20-NPT Aluminum A300-BAA-****-*** 10517-20-BSPT Aluminum 230 GASKET, AIR VALVE 1 All Models 12115-19 ‡ Nitrile 240 SHUTTLE PLATE 1 All Models 10414-26 ‡ Stainless Steel 250 SHUTTLE 1 All Models 10413-32 ‡ Special 260 AIR VALVE BODY 1 All Models 11613-20 ‡ Aluminum	180	DIAPHRAGM	2			
A300-*A*-G***-*** 10608-19-2PK Geolast® A300-*A*-S***-*** 10608-23-2PK Santoprene® San						
A300-*A*-S***-*** 10608-23-2PK Santoprene® A300-*A*-T***-*** 10608-23-2PK Santoprene® Santoprene® A300-*A*-T***-*** 10608-23-2PK Santoprene® Santop						
(BACKUP) A300-*A*-T***-***(PTFE) 10608-23-2PK Santoprene® 190 OVERLAY (PTFE ONLY) 2 A300-*A*-T***-*** 11407-59-2PK PTFE 200 & 210 OUTER DIAPHRAGM PLATE W/ THREADED STUD 2 A300-*AA-****-*** 11222-20 Aluminum 220 SUCTION MANIFOLD 1 A300-NAA-****-*** 10517-20-NPT Aluminum Aluminum 230 GASKET, AIR VALVE 1 All Models 12115-19 ‡ Nitrile 240 SHUTTLE PLATE 1 All Models 10414-26 ‡ Stainless Steel 250 SHUTTLE 1 All Models 10413-32 ‡ Special 260 AIR VALVE BODY 1 All Models 11613-20 ‡ Aluminum						
200 & 210 OUTER DIAPHRAGM PLATE W/ THREADED STUD 2 A300-*AA-****-*** 11222-20 Aluminum 220 SUCTION MANIFOLD 1 A300-NAA-****-*** 10517-20-NPT Aluminum 230 GASKET, AIR VALVE 1 All Models 12115-19 ‡ Nitrile 240 SHUTTLE PLATE 1 All Models 10414-26 ‡ Stainless Steel 250 SHUTTLE 1 All Models 10413-32 ‡ Special 260 AIR VALVE BODY 1 All Models 11613-20 ‡ Aluminum		(BACKUP)				•
220 SUCTION MANIFOLD 1 A300-NAA-****-*** 10517-20-NPT Aluminum Aluminum 230 GASKET, AIR VALVE 1 All Models 12115-19 ‡ Nitrile 240 SHUTTLE PLATE 1 All Models 10414-26 ‡ Stainless Steel 250 SHUTTLE 1 All Models 10413-32 ‡ Special 260 AIR VALVE BODY 1 All Models 11613-20 ‡ Aluminum	190	OVERLAY (PTFE ONLY)	2	A300-*A*-T***-***	11407-59-2PK	PTFE
A300-BAA-**** 10517-20-BSPT Aluminum 230 GASKET, AIR VALVE 1 All Models 12115-19 ‡ Nitrile 240 SHUTTLE PLATE 1 All Models 10414-26 ‡ Stainless Steel 250 SHUTTLE 1 All Models 10413-32 ‡ Special 260 AIR VALVE BODY 1 All Models 11613-20 ‡ Aluminum	200 & 210	OUTER DIAPHRAGM PLATE W/ THREADED STUD	2	A300-*AA-***-**	11222-20	Aluminum
230 GASKET, AIR VALVE 1 All Models 12115-19 ‡ Nitrile 240 SHUTTLE PLATE 1 All Models 10414-26 ‡ Stainless Steel 250 SHUTTLE 1 All Models 10413-32 ‡ Special 260 AIR VALVE BODY 1 All Models 11613-20 ‡ Aluminum	220	SUCTION MANIFOLD	1			
240SHUTTLE PLATE1All Models10414-26 ‡Stainless Steel250SHUTTLE1All Models10413-32 ‡Special260AIR VALVE BODY1All Models11613-20 ‡Aluminum						
250 SHUTTLE 1 All Models 10413-32 ‡ Special 260 AIR VALVE BODY 1 All Models 11613-20 ‡ Aluminum			1		· · · · · · · · · · · · · · · · · · ·	
260 AIR VALVE BODY 1 All Models 11613-20‡ Aluminum			1		· · · · · · · · · · · · · · · · · · ·	Stainless Steel
<u> </u>			1		· · · · · · · · · · · · · · · · · · ·	<u> </u>
270 AIR VALVE SPOOL 1 All Models 10412-31 ‡ Acetal			1		· · · · · · · · · · · · · · · · · · ·	
	270	AIR VALVE SPOOL	1	All Models	10412-31 ‡	Acetal


PARTS LIST - ALUMINUM, A300-*AA-***-***

ITEM	DESCRIPTION Q	lΤΥ	PUMP MODEL	PART NO.	MATERIAL
280	LIP SEAL (DIAPHRAGM ROD)	2	All Models	12003-76 ‡	Nitrile
290	O-RING (AIR VALVE END PLUG)	2	All Models	11913-11 ‡	Nitrile
300	AIR VALVE END PLUG	2	All Models	11706-20 ‡	Aluminum
311	MUFFLER	1	All Models Optional	13001-00 13009-20	Polypropylene Metal
312	MUFFLER PLATE	1	All Models Optional	13107-60 13107-20-125	Polypropylene Metal
321	MUFFLER GASKET	1	All Models	12108-11	Nitrile
322	O-RING (CHAMBER BOLTS)	10	All Models	11932-11	Nitrile
323	O-RING (CHAMBER/INTERMEDIATE)	2	All Models	11941-11	Nitrile
330	PIPE PLUG	2	A300-*AA-***-***	12205-42	Nylon
341	SCREW, PHILLIPS FLAT HEAD (#6-32 X 3/4")	6	All Models	12550-050-MS-26	Stainless Steel
342	SCREW, PHILLIPS PAN (#8-32 X 1")	6	All Models Optional	12531-075-MS-26 12531-113-26	Stainless Steel Stainless Steel
351	CAP SCREW (1/4"-20 X 3")	8	A300-*AA-***-*** Optional	12516-25 12516-26	Plated Steel Stainless Steel
352	CAP SCREW, SOCKET HEAD (5/16"-18 X 3/4")	10	All Models	12535-26	Stainless Steel
353	CAP SCREW (3/8"-16 X 1-1/4")	12	All Models	12534-25	Plated Steel
354	CAP SCREW (1/2"-13 X 1-1/2")	4	A300-*AA-****-*** Optional	12538-25 12538-26	Plated Steel Stainless Steel
355	CAP SCREW (1/2"-13 X 2-1/2")	24	A300-*AA-**** Optional	12522-25 12522-26	Plated Steel Stainless Steel
360	NUT, FLANGE (1/2"-13)	24	A300-*AA-**** Optional	12582-25 12582-26	Plated Steel Stainless Steel
371	WASHER, LOCK (1/4")	8	A300-*AA-***-*** Optional	12350-25 12350-26	Plated Steel Stainless Steel
372	WASHER, SPLIT LOCK (1/2")	28	A300-*AA-***-*** Optional	12323-25 12323-26	Plated Steel Stainless Steel
381	WASHER (5/32")	6	All Models	12311-26	Stainless Steel
382	WASHER (1/4")	8	A300-*AA-***-*** Optional	12300-25 12300-26	Plated Steel Stainless Steel
383	WASHER (3/8")	12	All Models	12303-25	Plated Steel
384	WASHER (1/2")	28	A300-*AA-***-*** Optional	12306-25 12306-26	Plated Steel Stainless Steel
385	WASHER, CUSTOM	2	All Models	12312-25	Plated Steel
390	N/A				
400	GROUNDING LUG (NOT SHOWN)	1	All Models	13480-20	Aluminum
	Magnalube .75 OZ.	As	Required, All Models	13404-00	Grease
	haracter				

 $[\]boldsymbol{\ddagger}$, $\boldsymbol{\Delta}$ Only sold as part of assembly

ASSEMBLY PART NUMBERS	PUMP MODEL	PART NO.	MATERIAL
‡ PILOT VALVE ASSEMBLY 80, 100, 110, 120, 130, 140	A300-*AA-***-**	APK-300-A	Various
Δ MAIN AIR VALVE ASSEMBLY 230, 240, 250, 260, 270, 280, 290, 300	A300-*AA-***-***	AMK-300-A	Various

STAINLESS STEEL, A300-FA3-***-***



PARTS LIST - STAINELSS STEEL, A300-FA3-***-***

ITEM	DESCRIPTION	QTY	PUMP MODEL	PART NO.	MATERIAL
10	DISCHARGE MANIFOLD	1	A300-FA3-***-**	10511-26	Stainless Steel
20	BALL	4	A300-*A*-*V**-***	11007-13-4PK	Viton®/FKM
			A300-*A*-*E**-***	11007-15-4PK	EPDM
			A300-*A*-*G**-***	11007-19-4PK	Geolast®
			A300-*A*-*N**-*** A300-*A*-*S**-***	11007-21-4PK 11007-23-4PK	Buna-N Santoprene®
			A300- A - 3 - A300-*A*-*T**-***	11007-23-4FK 11007-45-4PK	PTFE
30	VALVE SEAT	4	A300-*A*-** VV-***	10905-13-4PK	Viton®/FKM
			A300-*A*-** EE-***	10905-15-4PK	EPDM
			A300-*A*-** NN-***	10905-19-4PK	Buna-N
	(VALVE CEATC 4000E 40, 45 0, 40 HAVE		A300-*A*-**A*-***	10905-20-4PK	Aluminum
	(VALVE SEATS 10905-13, -15 & -19 HAVE INTEGRAL VALVE & 0-RING)		A300-*A*-**3*-*** A300-*A*-**Y*-***	10905-26-4PK 10905-42-4PK	Stainless Steel Nylon
40	O-RING (VALVE SEAT)	4	A300-*A*-***N-***	11934-11-4PK	Nitrile
40	O-MINO (VALVE SLAT)	4	A300-'A'-'***V-***	11934-11-4PK	Viton®/FKM
	(OPTIONAL- ONLY USED WITH VALVE		A300-*A*-***E-***	11934-15-4PK	EPDM
	SEATS 10905-20, -26 & -42)		A300-*A*-***T-***	11934-17-4PK	PTFE
50	OUTER CHAMBER	2	A300-FA3-***-**	10704-26	Stainless Steel
61	INTERMEDIATE	1	All Models	11520-A300-20	Aluminum
62	INNER CHAMBER	2	All Models	11802-20	Aluminum
70 & 90	DIAPHRAGM ROD ASSEMBLY	1	A300-FA3-***-***	35007-00	Stainless Steel
80	PILOT SLEEVE	1	All Models	10106-31 Δ	Acetal
100	INNER SPACER, PILOT SLEEVE	3	All Models	10205-40 Δ	Polypropylene
110	O-RING (PILOT SLEEVE SPACER)	4	All Models	11919-16 Δ	Urethane
120	END SPACER, PILOT SLEEVE	2	All Models	10206-40 Δ	Polypropylene
130	O-RING (END SPACER)	2	All Models	11919-11 Δ	Nitrile
140	LIP SEAL (AIR VALVE)	2	All Models	12002-76 Д	Nitrile
150	RETAINING PLATE	2	All Models	12712-A300-20	Aluminum
160	BUMPER	2	All Models	12309-16	Urethane
170	INNER DIAPHRAGM PLATE	2	All Models	11107-20	Aluminum
180	DIAPHRAGM	2	A300-*A*-N***-***	10608-11-2PK	Buna-N
			A300-*A*-V***-***	10608-13-2PK	Viton®/FKM
			A300-*A*-E***-*** A300-*A*-G***-***	10608-16-2PK	Urethane
			A300-*A*-S***-***	10608-19-2PK 10608-23-2PK	Geolast®
	(BACKUP)		A300-*A*-T***-***(PTFE)	10608-23-2PK 10608-23-2PK	Santoprene® Santoprene®
190	OVERLAY (PTFE ONLY)	2	A300-*A*-T***-***	11407-59-2PK	PTFE
200	N/A				
210	OUTER DIAPHRAGM PLATE	2	A300-FA3-***-**	11222-26	Stainless Steel
220	SUCTION MANIFOLD	1	A300-FA3-***-***	10510-26	Stainless Steel
230	GASKET, AIR VALVE	1	All Models	12115-19 ‡	Nitrile
240	SHUTTLE PLATE	1	All Models	10414-26 ‡	Stainless Steel
	SHUTTLE	1	All Models	10413-32 ±	Special
250		•		· · · · · · · · · · · · · · · · · · ·	<u> </u>
	AIR VALVE BODY	1	All Models	11613-20 +	Aluminum
250 260 270	AIR VALVE BODY AIR VALVE SPOOL	1	All Models All Models	11613-20 ‡ 10412-31 ‡	Aluminum Acetal



PARTS LIST - STAINELSS STEEL, A300-FA3-***-***

ITEM	DESCRIPTION	QTY	PUMP MODEL	PART NO.	MATERIAL
290	O-RING (AIR VALVE END PLUG)	2	All Models	11913-11 ‡	Nitrile
300	AIR VALVE END PLUG	2	All Models	11706-20 ‡	Aluminum
311	MUFFLER	1	All Models	13001-00	Polypropylene
			Optional	13009-20	Metal
312	MUFFLER PLATE	1	All Models	13107-60	Polypropylene
			Optional	13107-20-125	Metal
321	MUFFLER GASKET	1	All Models	12108-11	Nitrile
322	O-RING (CHAMBER BOLTS)	10	All Models	11932-11	Nitrile
323	O-RING (CHAMBER/INTERMEDIATE)	2	All Models	11941-11	Nitrile
330	PIPE PLUG	2	A300-FA3-***-**	12205-42	PTFE
341	SCREW, PHILLIPS FLAT HEAD (#6-32 X 3/4")	6	All Models	12550-050-MS-26	Stainless Steel
342	SCREW, PHILLIPS PAN (#8-32 X 1")	6	All Models	12531-075-MS-26	Stainless Steel
			Optional	12531-113-26	Stainless Steel
351	CAP SCREW (1/4"-20 X 3")	8	A300-FA3-***-**	12516-26	Stainless Steel
352	CAP SCREW, SOCKET HEAD (5/16"-18 X 3/4")	10	All Models	12535-26	Stainless Steel
353	CAP SCREW (3/8"-16 X 1-1/4")	12	All Models	12534-25	Plated Steel
354	CAP SCREW (1/2"-13 X 1-1/2")	4	A300-FA3-***-***	12538-26	Stainless Steel
355	CAP SCREW (1/2"-13 X 2-1/2")	24	A300-FA3-***-***	12522-26	Stainless Steel
360	NUT, FLANGE (1/2"-13)	24	A300-FA3-***-**	12582-26	Stainless Steel
371	WASHER, LOCK (1/4")	8	A300-FA3-***-**	12350-26	Stainless Steel
372	WASHER, SPLIT LOCK (1/2")	28	A300-FA3-***-***	12323-26	Stainless Steel
381	WASHER (5/32")	6	All Models	12311-26	Stainless Steel
382	WASHER (1/4")	8	A300-FA3-***-***	12300-26	Stainless Steel
383	WASHER (3/8")	12	All Models	12303-25	Plated Steel
384	WASHER (1/2")	28	A300-FA3-***-***	12306-26	Stainless Steel
390	N/A				
400	GROUNDING LUG (NOT SHOWN)	1	Optional	13480-20	Aluminum
	Magnalube .75 OZ.	As	Required, All Models	13404-00	Grease
* Any	Character		·		
- Λ	Only sold as part of assembly				

 \ddagger , Δ Only sold as part of assembly

ASSEMBLY PART NUMBERS	PUMP MODEL	PART NO.	MATERIAL
‡ PILOT VALVE ASSEMBLY 80, 100, 110, 120, 130, 140	A300-FA3-***-**	APK-300-3	Various
Δ MAIN AIR VALVE ASSEMBLY 230, 240, 250, 260, 270, 280, 290, 300	A300-FA3-***-**	AMK-300-3	Various



ELASTOMERS & REPAIR KITS

WETTED ELASTOMERS

BUNA-N (NITRILE)

is a general purpose elastomer used with water and many oils. Temperature range 10°F to 180°F (-12C to 82C).

GEOLAST®

is an injection molded thermoplastic material with characteristics similar to Nitrile. Has excellent abrasion resistance. Temperature range 10°F to 180°F (-12C to 82C).

EPDM

is a general purpose elastomer with good resistance to many acids and bases. Temperature range -40°F to 280°F (-40°C to 138°C).

SANTOPRENE®

is an injection molded material with characteristics similar to EPDM. Has excellent abrasion resistance. Temperature range -40°F to 225°F (-40°C to 107°C).

VITON®

is an elastomer with good corrosion resistance to a wide variety of chemicals. Temperature range -40°F to 350°F (-40°C to 177°C).

FKM

is an elastomer with good corrosion resistance to a wide variety of chemicals. Similar in chemical resistance to Viton®. Temperature range -40°F to 350°F (-40°C to 177°C).

PTFE (POLYTETRAFLUOROETHYLENE)

is a thermoplastic polymer that is inert to most chemicals. Similar in chemical resistance to Teflon®. Temperature range 40°F to 220°F (4C to 104C).

Most of the above elastomers are available in FDA approved formulations.

Viton® is a registered trademark of DuPont Performance Elastomers L.L.C. Geolast® is a registered trademark of ExxonMobil Chemical Co. Santoprene® is a registered trademark of ExxonMobil Chemical Co. Teflon® is a registered trademark of DuPont Performance Elastomers L.L.C. Magnalube® is a registered trademark of Carleton-Stuart Corp.



II 2 GD c TX

Warning: The TX marking refers to the maximum surface temperature depending not on the equipment itself, but mainly on operating conditions. In this case, the maximum surface temperature depends upon the temperature of the process fluids.

WARRANTY AND REGISTRATION

WARRANTY. All All-Flo products shall be covered by the standard All-Flo Limited Warranty in effect at the time of shipment. This warranty (which may be modified by All-Flo at any time) provides:

MATERIALS SOLD ARE WARRANTED TO THE ORIGINAL USER AGAINST DEFECTS IN WORKMANSHIP OR MATERIALS UNDER NORMAL USE (RENTAL USE EXCLUDED) FOR FIVE YEARS AFTER PURCHASE DATE. ANY PUMP WHICH IS DETERMINED TO BE DEFECTIVE IN MATERIAL AND WORKMANSHIP AND RETURNED TO ALL-FLO, SHIPPING COSTS PREPAID. WILL BE REPAIRED OR REPLACED AT ALL-FLO'S OPTION, CUSTOMER SHALL NOTIFY ALL-FLO IN WRITING WITHIN 30 DAYS OF ANY CLAIMED DEFECTS. NO MATERIALS CAN BE RETURNED WITHOUT THE PRIOR CONSENT OF ALL-FLO. AND IF APPROVED SHALL BE RETURNED TO ALL-FLO FREIGHT PREPAID. ALL-FLO'S LIABILITY FOR ANY BREACH OF THIS WARRANTY SHALL BE LIMITED TO EITHER REPLACEMENT OF THE MATERIALS OR, AT ALL-FLO'S SOLE OPTION, THE REFUND OF THE PURCHASE PRICE. ALL-FLO SHALL NOT BE HELD LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY BREACH OF THIS WARRANTY. THIS EXCLUSION APPLIES WHETHER SUCH DAMAGES WERE SOUGHT BASED ON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY IN TORT, OR ANY OTHER LEGAL THEORY. FURTHER, ALL-FLO SHALL NOT BE LIABLE FOR LOSSES, DELAYS, LABOR COSTS, OR ANY OTHER COST OR EXPENSE DIRECTLY OR INDIRECTLY ARISING FROM THE USE OF MATERIALS. ALL-FLO'S LIABILITY IS EXPRESSLY LIMITED TO THE REPLACEMENT OR REPAIR OF DEFECTIVE GOODS, OR THE TOTAL VALUE OF SUCH GOODS. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES. WHETHER EXPRESS. IMPLIED. OR ORAL INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, AND ANY IMPLIED WARRANTIES OTHERWISE ARISING FROM A COURSE OF DEALING OR TRADE. All-Flo will not, in ANY event, be liable for any loss of profit, interruption of business or any other special, consequential or incidental damages suffered or sustained by Customer. All-Flo's total maximum liability to the customer in respect of sale of materials or services rendered by All-Flo is limited to the total monies received by All-Flo from the customer for the particular. Materials described in Customer's order.

All-Flo does not warrant any part or component that it does not manufacture, but will assign to the original end-user purchaser of any warranty received by it from the manufacturer, to extent such pass through is permitted by the manufacturer

REGISTRATION FORM				
Pump Model		Pump Serial Numb	oer	
Company Name				
Name		Email		
Phone #	City			Zip
Qty of Pumps		Fluid Pumping		
How did you hear about us? Existing All-Flo user, Web, Distributor, Magazine				Scan QR code and
		<u> </u>		complete form on mobile phone

MAIL TO: All-Flo Pump Co. | Attn: Product Registration PO BOX 1870 | Mentor, OH 44061



www.all-flo.com/registration-form.html



ALL-FLO is committed to the pursuit of designing and manufacturing the highest quality product available to industry. Since the beginning in 1986, All-Flo engineers have used their extensive knowledge of today's engineered materials, advanced air system logic and manufacturing techniques to develop the superior group of lube-free, air-operated diaphragm pumps found in this catalog. Every pump is performance engineered and quality built to provide trouble-free service under the toughest conditions.

ALL-FLO PUMP CO.

7750 Tyler Blvd. Mentor, Ohio 44060 phone: 440.354.1700 fax: 440.354.9466 all-flo.com

13966-A300-M_Rev_C